




IMPERA i8

User manual



Foreword

Thank you for purchasing our product.

These operational guidelines for the user, to ensure you a quick and convenient use, read the instructions carefully.

This device is a specialized top quality portable table product with a series of remarkable functions. There will be no separate notice in the case of any change in content of this text.

This company will continue to provide new functions for the development of the product, and there will be no separate notice in the case of any change in the product's performance and functions. While this unit is used as a mobile storage device, this company will not be held liable for the security of files saved in the disk.

If the actual setup and the application methods are not identical to those as set forth in this manual, please access the latest product information of this company's website.

Contents

Foreword.....	2
Contents	3
Points for Attention	4
Shapes and Keys	5
Buttons description and application.....	6
Desktop introduction.....	7
App interface introduction.....	9
Specifications.....	13
Declaration of conformity.....	14

Points for Attention

1. Do not use the tablet in exceptionally cold or hot, dusty, damp or dry environments.
2. Do not allow the tablet to fall down while using it.
3. Please charge your battery when:
 - A. Battery symbol shows an empty icon;
 - B. The system automatically shuts down and the power is soon off when you switch on the unit once again;
 - C. There is no response if you operate on any key
4. Please do not disconnect power when the tablet is being formatted or in the process of uploading or downloading. Otherwise it may lead to the error in the program.
5. When this unit is used as a moving disk, the user shall store or export files in the proper file management operation method. Any improper operation method may lead to the loss of files, for which this Company will be held no liable.
6. Please do not disassemble this unit by yourself. If you encounter any malfunction, please contact the dealer.
7. There will be no separate notice in the case of any change in the functions and performance of this product.

To avoid the problems that might occur with the service shops approved by Visual Fan Ltd. (because Visual Fan reserves the right to stop the collaboration with any service shop which was previously approved and mentioned in the warranty card on the date on which the product batch was sold on the market), before taking a product to the service shop, please check the updated list of approved service shops on Allview website at the section: “Support&Service – Approved service”.

We do not assume the responsibility in case the product is used other way than stated in the user guide. Our company reserves the right to bring modifications in the content of the user guide without making this fact public.

All the modifications will be listed on the company website (www.allviewmobile.com) in the section dedicated to the specific product which is subject to modifications. The content of this guide may vary from the one existing in electronic format within the product. In such case the latter one will be taken into consideration.

Shapes and Keys



1. Front camera

2. USB socket

3. HDMI socket

4. Earphone socket

5. SD card socket

6. MIC

7. Power switch

8. Volume key

9. Loudspeaker

10. Rear camera

Buttons description and application

Note: The keyboard is optional (not included) and will be used according to product configuration.



- 1、 Fixed tablet: easy alignment and fixed tablet.
- 2、 Keyboard form: provide a QWERTY keyboard set of buttons and provide excellent typing comfort.
- 3、 Base: folding base of tablets.

The use of tablet with the keyboard



Desktop

1、 The desktop presentation: In Windows 8.1 start screen you can see many applications in fixed positions as in the picture that will display in form of "magnet", with easy access of one click.

Before using applications in full need to login to your Microsoft account first.



2、 Picture slide application

Slide to the right



Slide from the left side to the right side of the screen in order to open the running application screen.

Slide to the left



Slide from the right side to the left side of the screen to open the menu bar.

Zoom Out



Two fingers together on the touch screen to shrink.

Zoom In



Separate two fingers on the touch screen to zoom in.

Slide down sliding



In the start screen, slide down from the top to display customization options.

Fingers sliding



Slide from the center of the screen to the left or to the right to move around the screens.

Slide down sliding

At the start of the screen, from underneath the screen sliding upwards to show the application or screen options.

App interface introduce


In start screen you can also expand to see all applications available if slide upwards.



If you want to fix more applications in start screen, please light touch as in (1) and hold the application magnet for about 1 second, let go, select (2) and now application is fixed to the start screen.



In start screen if you want to remove, or delete an application, (1) light touch and hold the application magnet for about 1 second, and then let go run, select (2)



attribute column, remove fixed, delete, etc. The application can be completed.

Charm menu bar

Slide from the right side of the screen to the left, to unlock Charm menu bar including: start, equipment, share, search program.



Allows you to search for files or applications in tablet.



Allows you to share through social networks or email program.



Can return to the start screen; From the start screen you can also use this function to return to recently opened applications.




Allows you to connect to the tablet devices to read and write and share files, an external screen or printer.



Allows you to enter tablet PC Settings.

Search menu




Share menu



Equipment menu



Settings menu



Double screen app

1、 As in (figure 1) in the left picture, from the left side of the screen if stall in sliding you can open double interface.

2、 As in (Figure 2), press and hold the middle button dividing line and split, drag, and dual display scale can be divided.



(Figure 1)



(Figure 2)


Basic operation

1、Standby, restart, turning off



2、Safety management

User and password



Fast method Settings:

Click on the "Charm" set the "set" button, select "more PC Settings". Choose "user" on the left of the Settings, and click the "your account" on the right side of "create the local account". After input complete Windows live ID account password, enter the user name, password and confirm password.

Specifications

General	Dimensions	206,5x122,5x9 mm
	Weight	358,6 g
Display	Type	8" IPS LCD, 1280x800 px
Characteristics	OS	Windows 8.1
	CPU	Quad Core Intel Atom Processor Z3735E with up to 1.8GHz
	GPU	Intel HD Graphics
	Flash memory	16GB
	RAM memory	1GB DDR3
Connectivity	WLAN	WiFi 802.11 b/g/n
	Bluetooth	Yes v4.0
	PC connectivity	Yes, USB 2.0
Multimedia	Camera	5Mpx / 2Mpx
	Sound	Two stereo speakers
		Earphones plug
		Integrated microphone
Ports	Audio out	Jack 3,5 mm
	Video out	Micro HDMI
	Card reader	MicroSD
	Usb	MicroUSB
Battery	Battery type	3,7V Li-Po
	Capacity	3800 mAh
	Charger type	DC 5V, 2A

DECLARATION OF CONFORMITY

Nr.1307 - 24.06.2014

We, SC VISUAL FAN SRL, importer located in Brasov, 61 Brazilor

STR., 500313, registered at the Commerce Chamber Brasov no. J08/818/2002, CUI 14724950, assures, guarantee and declare on our own responsibility, in accordance with art.4 from HG nr. 1.022/2002 regarding the statute of the products and services that can jeopardize life, health, work security and environmental protection, that:

The product Impera i8 tablet PC, ALLVIEW brand and the accessories that came with the product: 220V charger, headphones and battery don't jeopardize life, health, work security and environmental protection and they are according to:

- The Stipulations of HG nr.982/2007 witch transpose the essential requirements specified in Direction 2004/108/CE, regarding electromagnetically compatibility;
- The Direction regarding the low voltage equipment users assurance 73/32/CEE, modified by Direction 93/68/CEE (HG 457/2003) and tests EN 55013:2001+A1:2003+A2:2006, EN 55020:2007, EN 61000-3-2:2006, EN 61000-3-3:1995+A1:2001+A2:2005;
- The Direction regarding the radio and telecommunication equipments R&TTE 1999/5/CE (HG 88/303).
- The safety requirements of the European Directive 2001/95/EC and of EN standards 60065:2002/A12:2011 and EN 60950-1:2006/A12:2011, EN62209-1(2006), EN62311(2008) of the decibels level emitted by the sold devices.

The Product described upstairs in this Declaration and all the accessories are according to the next standards:

- Health EN 50360, EN 50361;
- Safety EN 6095-1;
- EMC EN 301 489-1-7/17;
- Radio spectrum EN 301511 EN 300328;

After the performed tests emerge that the samples comply with the upstairs specification, as the test results show. Documentation is stored on VISUAL FAN LTD - Brasov, 61 Brazilor STR.

Also available on web: <http://allviewmobile.com>


Director
Cotuna Gheorghe





IMPERA i8

Manual de utilizare



Cuvânt înainte

Vă mulțumim că ați achiziționat produsul nostru.

Aceste orientări operaționale pentru utilizator, pentru a asigura o utilizare rapidă și comodă, citiți instrucțiunile cu atenție.

Acest dispozitiv este o tabletă portabilă specializată de o înaltă calitate cu o serie de funcții remarcabile. Nu va fi o notificare separată în caz de modificare a conținutului companiei. Aceasta companie va continua să furnizeze noi funcții pentru dezvoltarea performanțelor și funcțiilor produsului. Deoarece acest produs este utilizat ca un mediu de memorie mobil, compania nu poate fi trasă la răspundere pentru securitatea fișierelor salvate pe disc.

Dacă aceste configurări actuale și metodele aplicației nu sunt identice cu cele prezentate în acest manual, accesați ultima informație a site-ului acestei companii.

Sumar

Cuvânt înainte	16
Sumar.....	17
Puncte de aten ie	18
Forme i taste.....	29
Descrierea butoanelor i aplica ii.....	20
Prezentare desktop	21
Introducerea interfe ei aplica iei	23
Specifica ii.....	28
Declarație de conformitate.....	29

Puncte de aten ie

1. Nu utiliza i tableta în medii excep ional de reci sau calde, cu mult praf, umede sau uscate.
2. Nu permite i tabletei să se oprească în timpul utilizării.
3. Încărca i bateria când:
 - A. Simbolul bateriei afi ează o pictogramă goală;
 - B. Sistemul se închide automat i telefonul se opre te imediat ce încerca i să-l porni i;
 - C. Nu există niciun răspuns după ce apăsa i orice tastă.
4. Nu deconecta i de la sursa de încărcare când tableta este formatată sau în procesul încărcării sau descărcării. Altfel, poate duce la eroare în program.
5. Când această unitate este utilizată ca un disc mobil, utilizatorul poate memora sau exporta fi iere în metoda potrivită a opera iunii de administrare a fi ierelor, iar această companie nu poate fi trasă la răspundere.
6. Vă rugăm să nu demonta i această unitate singuri. Dacă vă confrunta i cu orice disfunc ie, vă rugăm să contacta i distribuitorul.
7. Nu va fi emisă o notificare separată în caz de modificare în func iile i performan ele acestui produs.

Pentru a evita probleme care pot sa apară cu service-uri care nu mai sunt agreate de către SC Visual Fan SRL (deoarece Visual Fan își rezervă dreptul de a înceta colaborarea cu orice service colaborator agreat, existent pe certificatul de garanție la data punerii în vanzare pe piață a lotului de produse), înainte de a duce un produs in service va rugăm sa consultați lista actualizată a serviceurilor agreate, existentă pe siteul Allview la secțiunea „suport&service-service autorizat”.

Nu ne asumăm responsabilitatea pentru situațiile in care produsul este folosit in alt mod decat cel prevăzut in manual. Compania noastră isi rezervă dreptul de a aduce modificări în continutul ghidului fără a face public acest lucru. Aceste modificări vor fi afișate pe siteul companiei (www.allviewmobile.com) in secțiunea dedicată produsului căruia i se aduc modificări.

Conținutul acestui ghid poate fi diferit de cel existent in format electronic in produs. In acest caz ultimul va fi luat in considerare.

Forme i taste



1. Camera foto frontală

2. Mufă USB

3. Mufă HDMI

4. Mufă că ti

5. Slot card SD

6. Microfon

7. Buton pornire

8. Tasta de volum

9. Difuzor

10. Camera foto spate

Descrierea butoanelor i aplica ie

Notă: Tastatura este oopțională (neinclusă) și va fi utilizată in funcție de configurația produsului.



- 1、 Tabletă fixată: aliniament facil i tabletă fixă
- 2、 Forma tastelor: furnizează un set de taste QWERTY i asigură un confort de tastare excelent.
- 3、 Bază: plierea bazei husei tabletei

Utilizarea tabletei cu tastatura




Desktop

1, Prezentare desktop : Pe ecranul de start al Windows8.1, pute i vizualiza multe aplicații in poziții fixe care vor fi afișate in formă de „magnet”, cu acces facil printr-un singur click.

Înaintea de rularea in mod complet a aplica ii trebuie să vă înregistra i mai întâi în contul

Microsoft



2, Aplica ia de glisare a imaginii

Glisa i spre dreapta



De pe ecranul din stânga glisa i spre dreapta pentru a deschide lista.

Glisa i spre stânga



Glisa i spre stânga din partea dreaptă a ecranului pentru a

deschide bara de meniu

Mic orează



Apropiati două degete pentru a micșora

Glisa i în jos



În ecranul principal glisați din partea de sus a ecranului pentru a vizualiza opțiuni de personalizare



Măre te



Separa i două degete pe ecran pentru a mări

Glisare cu degetele



În ecranul principal glisa i cu degetele pentru a vă deplasa pe ecran

Glisarea de jos în sus

Glisati din partea de jos a ecranului pe a afisa opțiunile aplicației sau ecranuli activ

Introducerea interfeței de aplicații

În ecranul principal puteți de asemenea să vizualizați toate aplicațiile glisând de jos în sus.




Dacă doriți mai multe aplicații fixate pe ecran apăsați ușor ca (1) și țineți apăsată pictograma aplicației pentru 1 secundă, eliberați, rulați, selectați (2) și este fixată în ecranul de pornire.




La pornirea ecranului, pe de altă parte, doriți să eliminați sau să ștergeți o aplicație, (1) apăsați ușor și țineți apăsată aplicația pentru aproximativ 1 secundă, eliberați,

rulați, selectați (2)
coloana de atribute,
eliminați-le pe cele
fixate, ștergeți, etc.
Aplicația poate fi
finalizată.



Bara de meniu charm

Glisați de la dreapta la stânga pentru a debloca bara de meniu Charm care include:
start, echipament, distribuire, program de căutare.



Vă permite căutarea fișierelor și aplicațiilor în tabletă.



Vă permite distribuirea prin intermediul rețelelor de socializare sau programului

de e-mail.



Puteți reveni la ecranul de start; și de la ecranul de start puteți utiliza această funcție pentru a reveni la aplicațiile recent deschise.




Vă permite conectarea la dispozitivele tabletei pentru a citi, scrie și distribui fișiere, conectare la un ecran extern sau o imprimantă.




Vă permite accesarea Setărilor tabletei.

Meniu de căutare




Distribuire meniu



Meniu echipament



Meniu de setări




Aplicație ecran dublu

1、Porniți ca în (Figura 1) din partea stângă a ecranului pentru a stagna glisarea și vizualizați deschiderea interfeței duble.

2、 Ca în (Figura 2), țineți apăsat butonul din mijloc de pe linia ce împarte ecranul și glisați, în acest fel dimensiunea ecranului putând fi împărțită în două.




(Figura 1)



(Figura 2)


Operațiuni de bază

1、 Hibernare, repornire, oprire



2、 Administrarea securității

Utilizator și parolă



Metodă rapidă de setare:

Apăsați "Charm" apăsați butonul "setare", selectați "mai multe Setări PC". Selectați "utilizator" în partea stângă a Setărilor, și introduceți "contul dvs." în partea dreaptă a "creare cont local". După introducerea completă a parolei contului Windows live ID, introduceți numele utilizatorului, parolă, confirmați parola când vi se cere aceasta.

Specificații

General	Dimensiuni	206,5x122,5x9mm
	Greutate	358,6 g
Ecran	Tip	8" IPS LCD, 1280x800 px
Caracteristici	SO	Windows 8.1
	CPU	Quad Core Intel Atom Processor Z3735E with up to 1.8GHz
	GPU	Intel HD Graphics
	Memorie Flash	16GB
	Memorie RAM	1GB DDR3
Conectivitate	WLAN	WiFi 802.11 b/g/n
	Bluetooth	Da 4.0
	Conectivitate PC	Da, USB 2.0
Multimedia	Camera	5Mpx / 2Mpx
	Sunet	Doua difuzoare stereo
		Iesire casti
		Microfon incorporat
Porturi	Iesire audio	Jack 3,5 mm
	Iesire video	Micro HDMI
	Cititor card	MicroSD
	Usb	MicroUSB
Baterie	Tip Baterie	3,7V Li-Po
	Capacitate	3800 mAh
	Tip incarcator	DC 5V, 2A

DECLARATIE DE CONFORMITATE

Nr. 1307 - 24.06.2014

Noi Visual Fan SRL, cu sediul social in Brasov, Str Brazilor nr 61, 500313

Romania, inregistrata la Reg. Com. Brasov sub nr. J08/818/2002, CUI RO14724950, in calitate de importator, asiguram, garantam si declaram pe proprie raspundere, conform prevederilor art. 4 HG nr.1.022/2002 privind regimul produselor si serviciilor care pot pune in pericol viata sanatatea, securitatea muncii si protectia muncii ca produsul Impera i8, tableta PC, marca ALLVIEW, nu pune in pericol viata, sanatatea, securitatea muncii, nu produce impact negativ asupra mediului si este in conformitate cu:

-Directiva privind echipamente radio si de telecomunicatii R&TTE 1999/5/CEE (HG 88/303)

-Directiva privind asigurarea utilizatorilor de echipamente de joasa tensiune 73/32/CEE, modificata de Directiva 93/68/CEE (HG457/2003)

-Directiva cu privire la compatibilitatea electromagnetica 89/336/CEE, modificate de Directiva 92/31/CEE si 93/68/CEE (HG497/2003)

-Cerintele de siguranta ale Directivei Europene 2001/95/EC si a standardelor EN 60065:2002/A12:2011 si EN 60950-1:2006/A12:2011, EN62209-1(2006), EN62311(2008) referitor la nivelul de decibeli emis de aparatele comercializate.

Produsul a fost evaluat conform urmatoarelor standarde:

-Sanatate EN 50360, EN 50361

-Siguranta EN 6095-1

-EMC EN 301 489-1/-7/-17

-Spectru radio EN 301511, EN 300328

Produsul are aplicat marcajul CE.

Procedura de evaluare a conformitatii a fost efectuata in conformitate cu prevederile Anexei II a HG nr. 88/2003, documentatia fiind depozitata la SC Visual Fan SRL, Brasov str. Brazilor nr.61, 500313.

Declaratia de conformitate este disponibila la adresa www.allviewmobile.com.

Director
Cotuna Gheorghe

